

21. Use the plug of the oil pot to block the oil pot, remove the syringe and use the T15 ring wrench to lock the screw of the oil filling port of the caliper, Simply wipe the oil filler port with detergent and a cleaning cloth.

\*The torque value of the caliper oil filling port screw is 5-7N.m Use the oiler plug to block the oiler After removing the syringe, tighten the screw and wipe it clean 22. Take out the plug of the oiler. When the oil volume of the oiler is more than 1/3, adjust the angle of the handlebar continuously, and press the brake handle several times until the handle feels stiff. "If the handle is not stiff, please repeat step 14, to step 20 Remove oiler plug There is a stiff feeling when pressing, and the adjustment is complete

23. Insert the oiler plug to remove the oil filling funnel.
24. Use a 2mm hex wrench to tighten the oil filling screw at the top of the shifter.
\*The torque value of the oil injection screw at the top of the shifter is 1-1.5 N\*m

In order to get a better brake feel, we need to continue to adjust the oil injection:

If the brake feel deteriorates after a period of use, this method can be used to

Finally tighten the sc use a cleaning cloth to wipe off the oil stains on the surface 25. Reset the rubber sleeve, adjust the shifter on the handlebar to a position suitable for you to hold, and tighten the screws; finally, put back the brake pads, cooling fins and springs on the caliper and fix them.

Effect diagram after installa Now that the installation is complete, you can continue to install and debug other components Thank you again for choosing and using L-TWOO products!

a. Tighten the oil filling screw and unscrew the exhaust screw.

adjust it again.

b. Use a needle oiler to inject a small amount of oil into the vent hole. (add the oil little by little until all the air inside is exhausted).